



<b>LEGEND:</b> ——— Factory Line Voltage Wiring ——— Factory Low Voltage Wiring - - - - - Optional Wiring - - - - - Option Box High Pressure Switch Loss of Charge Switch Sensor, Water Coil Freeze Protection RV Solenoid Coil	RELAY/ACTUATOR COIL CAPACITOR OPTIONAL ITEMS BUTT CONNECT MULTI SPLICE CONNECTOR Wire Nut	<b>CRC</b> Compressor Run Capacitor <b>COMPR</b> Compressor <b>HP</b> High Pressure Switch <b>HPWS</b> High Pressure Water Switch <b>LTS</b> LOW TEMP SWITCH <b>LOC</b> Loss of Charge <b>RVS</b> Reversing Valve Solenoid <b>SAC</b> Start Assist Capacitor <b>TBLK</b> Terminal Block <b>MWV</b> Motorized Water Valve	<b>NOTES:</b> 1. Ext. Compr. Overload on Sizes 09, 12, 15 & 18 Only. 2. Used with TRM24/30/36 COMPR PLUG only.
---	--	---	--



REFERENCE SKETCHES. DO NOT SHIP WITH UNIT