

WSTAT Water Stat

ECM1. For ECM Blower Motor air flow adjustment and diagnostic information refer to I.O.M.

HWG3. WSTAT is supplied with unit and must be wired in series with the hot leg to the pump. WSTAT is rated for voltage up to 277V.

LON1. Refer to LON, OR TSTAT Installation, Application, and Operation Manual for control wiring to the unit.

LON2. Optional LON wires. Only connect if LON connection is desired at the wall sensor.

LON6. Factory cut JW1 jumper. Dry Contact will be available between AL1 and AL2.

MOD1. For Modulating Water Valve option, place jumper on 0-10V pins.

MOD2. For Modulating Water Valve option, ensure actuator direction switch is set as shown. See Manual for Control Wiring to the unit.

