

BM11. Blower motor is factory wired for high & low speeds. For any other combination of speeds, at the motor attach the black wire to the higher of the two desired speed taps, and the red wire to the lower of the two desired speed taps.

MPC2. Refer to MPC Installation application, and Operation Manual For Control Wiring to the unit.

MPC3. ASW sensors are not required on Water-Water application. ASW06-ASW08 (Water-Air Only) move jumper to LSTAT, ASW09-ASW11 move jumper to Rnet.

MPC8. Factory cut JW1 jumper. Dry Contact will be available between AL1 and AL2

