



- NOTES:**
1. Compressor and Blower Motor thermally protected internally.
 2. All wiring to the unit must comply with NEC and local codes
Low Voltage Wiring shall be Class 2 or Equivalent.
 3. Field Use Only: Transformer wiring is voltage sensitive. Use layout corresponding to the unit voltage.
 4. LT1 provides low temperature protection for WATER. When using ANTI-FREEZE solutions, cut JW3 jumper.
 5. Typical heat pump thermostat wiring shown. Refer to thermostat IOM for wiring to the unit. T-Stat wiring must be "Class 1" and Voltage Rating equal to or greater than unit supply voltage.
 6. 24V alarm signal shown. For Dry Alarm contact between AL1 & AL2, cut JW1 for CXM/DXM Gen2 or JW4 DXM.
 7. Transformer Secondary Ground via control board standoffs and/or Common to Control Box.

BM5. For dual point power option, (QTY.3X) blower wires will go to PDB2 only.

PMP6. T1 and T2 for 203-230V/3ph. P1 and P2 for 460V/3ph and 575V/3ph

