

NOTES:

- BM10. Higher numbered taps take priority.
- HWG1. HWG and Heat Exchanger Pump only in models with Hot Water Generator option
factory default temperature setting is 125° F, for 150° F setting Anti-Scald Valve
must be used. See unit IOM for instructions.
- HWG3. AQUA STAT is supplied with unit and must be wired in series with the hot
leg to the pump. Aqua stat is rated for voltage up to 277V.
- MPC2. Refer to MPC Installation application, and Operation Manual For Control Wiring
to the unit.
- MPC3. ASW sensors are not required on Water-Water application. ASW06-ASW08
(Water-Air Only) move jumper to LSTAT, ASW13-ASW15 move jumper to Rnet.
- MPC8. Factory cut JW1 jumper. Dry Contact will be available between AL1 and AL2
- SAC3. Use Start Assist Capacitor only on unit size 015-018.

